

smartscan™

Fusion Sport's SMARTSPEED system has changed the face of data collection and training, enabling users to collect data straight into Windows Mobile and do away with pens and clipboards.

SMARTSCAN takes the system to another level, now completely automating the processes of data collection and training feedback. With the integration of Radio Frequency Identification (RFID) SMARTSPEED is now the world's only fully automated testing and training system.

how it works...

Each athlete is given a unique rubber bracelet containing an RFID electronic chip. By attaching a SMARTSCAN RFID reader to the start gate of any SMARTSPEED drill, the player is able to automatically identify themselves to the system, simply by touching their wrist on the reader, and waiting for the green light to tell them the system is ready for them to start. The involvement of the coach is simple - set up the system, choose the drill, and that's it. Everything else is completely automatic. It really is as simple, yet incredible, as it sounds.

completely automatic data capture

Even though SMARTSPEED has always offered simple data collection directly into MS Windows, there has always been one element of involvement required from the coach - choosing which player goes next. SMARTSCAN removes this final administrative step, allowing the coach to remain completely focused on coaching.

benefits for all users

- ▶ Ideal for large group testing such as talent identification schemes, combines and team testing
- ▶ Set up your SMARTSPEED system and leave it as a station in circuit training - athletes just walk over and use it when ready
- ▶ Monitoring - collect regular data on your athletes without any effort.
- ▶ Get more value from your SMARTSPEED system - set up your system before training and it will do the rest.



technical specifications

- ▶ Bands: silicon rubber, waterproof, passive chip (no batteries), reusable
- ▶ Read range: semi-contact
- ▶ Readers: 125KHz frequency, connect to SMARTSPEED remote unit via PS2 port
- ▶ Y-connector cable available for combining reader with jump mat
- ▶ PC-USB reader also available for event registration (pictured left)



for more information

please contact FUSION SPORT

e: smartspeed@fusionsport.com

or visit our website to find your nearest distributor-



fusion sport™

www.fusionsport.com